# Induction Sensor Head

# Model No.: ER, EW, EC, ED, ED(C), EB, EB(C)

FC C CE RoHS emc


Model	Product name	Product pictrue	Size	Sensor data
ER	PIR Motion Sensor		19.0 mm O O	Sensitive field: ≤3m Sensitivity angle: 120
EW	Wood Touch Sensor		19.0 mm O	Dimming range: 0-100% PWM Frequency: 2KHz Detective distance: ≤5cm
EC	Touch Sensor		19.0 mm O H4.5mm, Ø5mm	Dimming range: 0-100% PWM Frequency: 128Hz
ED ED(C)	Door Sensor	ED ED(C)	19.0 mm 31.50 mm 231.50 mm 31.50 mm	Detective distance: ≤10cm Detevtive angle: 15-30
EB EB(C)	Hand Sweep Sensor	EB EB(C)	19.0 mm 8 12.5 mm 12.5 mm 13.00 mm	Detective distance: ≤8cm Detevtive angle: 15-30

# **Features**

- Powered by low voltage 5VDC, output 5V level or PWM signal.
- PIR motion sensor: when people or objects enter the sensitive field, the light turn on; when these exit the sensitive field, the light turn off after 30 seconds.
- Wood touch Sensor: the medium can be wood, glass or plastic.

  Short touch the sensing area to turn on or turn off light; long touch the sensing area to dimming up or down.
- Touch sensor: short touch the LED to turn on or turn off light; long touch the LED to dimming up or down.
- Door sensor: when the door open, or no obstacle ahead, the light turn on gradually; when the door close, or obstacle ahead, the light turn off gradually.
- Hand sweep sensor: when hand sweep, the light turn on gradually; when hand sweep again, the light turn off gradually.

## Sensor wire define



User Manual Ver 1.0.1


# Induction sensor head installation and application

### ER: PIR Motion Sensor

## Ceilling mounting pattern


# 1. Out of sensing range (Light off ) 2. Sensing human activity (Light on) 3. Light off when go away (Automatically turn off)

## Wall mounting pattern




When installing, please pay attention to choosing a proper position and angle, otherwise the sensing distance will be very close or the sensing will be insensitive


## EW: Wood Touch Sensor




## EC: Touch Sensor



# ED / ED(C): Door Sensor



## EB / EB(C): Hand Sweep Sensor



User Manual Ver 1.0.1